

# PVC/Aluminum KURANDA Bed Assembly Instructions

## Parts:

- Fabric mat (+ 2 long, 2 short plastic rods for fabrics \*EXCEPT vinyl)
- slotted rails for frame – 2 long/2 short, 4 legs w/insert caps
- 4 Top corner brackets
- 4 Bottom corner brackets
- 8 screws, 8 nuts & split washers (+ 4 screws for aluminum legs only)
- NOTE: 44" XL and 50" XXL PVC rails have reinforcement rods inside

## Tools Needed:

- Phillips head screwdriver (powered may be needed)
- 7/16" wrench (or adjustable)
- Protected flat surface (table is ideal)

