

KURANDA Bed Assembly Instructions - Both PVC & Aluminum Beds

Parts:

- Fabric mat, ¼" black rods – 2 long/2 short (for non-vinyl fabric only)
- 1 5/8" slotted rails – 2 long/2 short
- 4 Top corner brackets
- 4 Bottom corner brackets
- 8 screws and 8 nuts for corners
- 8 split washers
- 4 legs, and 4 leg caps
- 4 set screws (for Aluminum beds only)

Tools Needed:

- Phillips head screwdriver
- 7/16" wrench (or adjustable)
- flat surface (table is ideal)

