

Data Sheet:

## Classic-Check® Models 72020 & 72021

### Classic Features for Fall Risk Monitoring

Since 1978, STANLEY Healthcare's Bed-Check has been designing and manufacturing fall and restraint reduction monitoring systems. Our Bed-Check monitors continue to offer what caregivers want most:


**Reliability. Simplicity. Versatility.**

### Product Overview

- Day/Night Mode features 1-touch control with 7 volume settings
- Ten programmable alarm tone settings
- Nurse call system compatibility
- The Classic-Check Model 72021 has a nurse call accessory port, which may eliminate the need for a Y-adaptor
- Variable delay settings: 1, 2, or 3 seconds
- No on-off switch: monitors automatically with weight on the Sensormat pad, and meets Joint Commission requirements
- Hold Mode: enables transfer of patient or resident by staff without alarm sounding
- Monitoring automatically restarts within 25 seconds when patient is on Sensormat pad even if the system has been placed in Hold mode
- Choice of mounting options
- Sensormat pads available for both bed and chair
- Integrated 10-foot power cord and nurse call cord
- Assembled in the USA; Two-year limited warranty

### Purpose

The Classic-Check control unit is intended to be used in conjunction with a STANLEY Healthcare Sensormat® pad as a system to effectively monitor patients at risk of falling or residents in a bed or stationary chair. Classic-Check provides an audible alarm to alert the caregiver when the person begins to get up unassisted.



## Data Sheet: Classic-Check® Models 72020 & 72021

### Power Requirements

The Classic- Check is powered by plugging the integral power supply into a standard wall outlet (110VAC). Power is converted to 12VDC before entering the Classic-Check case (no line voltage in the monitor).

### Installation

The Classic-Check may be mounted on the bed headboard or frame, on the head wall, or the chair back using the standard Velcro® strap or optional wire holster. It should be positioned so that it is inaccessible to the monitored person. The appropriate Sensormat pad is installed according to its own in-service instructions. See the Classic-Check User Guide for complete instructions.

### In-Service

Ask your professional Bed-Check Distributor about in-service training options.

### Features and Operation

Classic-Check has many standard features designed to effectively monitor patients at risk of falling.

- Begins monitoring immediately after pushing RESET whenever a patient is on the Sensormat pad
- Begins monitoring automatically 5 seconds after patient weight is detected on the Sensormat pad
- The Classic-Check sounds an audible alarm tone and can signal the nurse call system
- One touch HOLD starts a 25 second delay, during which the patient can be repositioned or assisted off the Sensormat pad without causing the system to alarm
- Day and Night modes: Setting to "Nite" illuminates the splash shield with a soft blue light and changes the alarm volume to your pre-set "Nite" level.
- LEDs indicate HOLD and MONitor modes, and the 1, 2, or 3 second delay countdown
- 4 tone and 6 tune settings
- Integrated 10-foot power cord
- 110V AC powered
- ETL listed. Conforms to UL® Standard 1069 and to CSA Standard C22.2 No. 205R